



TECHNICAL DATA

Deck & Fence

PRESSURE WASHER CONCENTRATE

DESCRIPTION

Recommended uses:

DECK & FENCE CLEANER

The proprietary formulation of Krud Kutter Deck & Fence Cleaner contains "Sporex", a unique additive which removes tough stains from mildew, mold, algae, fungus and moss, and leaves the surface completely clean. In addition, special surfactants penetrate the surface to safely and easily dissolve the toughest stains from dirt, oil, grease, bird droppings, tree sap, and acid rain. Even removes gray weathering on wood, chalking, and oxidation.

COVERAGE: 2000sq.ft./gallon

COLOR: Blue

PACKAGING/CONTAINERS:
Available in 1gal.

TECHNICAL DATA

Physical Data:

CONTAINS: A proprietary blend of biodegradable surfactants, detergents, and emulsifiers, in a water-based solution. No petroleum solvents, bleach or ammonia.

FLASH POINT: N/A
SHELF LIFE: N/A
VOC: 0

FOR EMERGENCY CALL
CHEMTREC (800-424-9300)
INTERNATIONAL (703-527-3887)
(COLLECT CALLS ACCEPTED)

APPLICATION

Directions for use:

DIRECTIONS FOR PRESSURE WASHER APPLICATION:

1. Wet the surface to be cleaned, prior to applying the product.
2. Place detergent application siphon tube and screen filter directly into container. Open meter valve (if applicable) for maximum product flow. For reservoir machines, pour product (full strength) into pressure washer.
3. Spray at low pressure onto a wet surface.
4. On vertical surfaces, always spray from the top down.
5. Allow product to remain on the surface for 3 to 5 minutes to penetrate. Do not allow product to dry on surface.
6. Remove siphon tube from solution and rinse surface with high pressure spray thoroughly.
7. Flush siphon tube with clean water prior to storage.

DIRECTIONS FOR MANUAL APPLICATION:

1. Wet the surface to be cleaned, prior to applying the product.
2. Mix approximately 12 oz. of product with 1 gallon of water in a bucket. Severe stains may require a larger amount of concentrate per gallon.
3. Clean in sections with a soft bristle brush, working from the top down on vertical surfaces.
4. Allow product to remain on surface for 3 to 5 minutes, but not dry.
5. With a hose at highest pressure, rinse the cleaner from the surface
6. Move to a new section and repeat the process.

IMPORTANT:

- When using a pressure washer to clean painted surfaces, please be aware that water pressure alone may remove paint, or highlight existing discoloration caused by the sun's UV.

IMPORTANT CONTINUED:

- From the garden hose, rinse any nearby plants with clean water.
- Always test on an inconspicuous area first.
- Any overspray can be neutralized with large volumes of water.
- On extremely soiled or mildewed surfaces it may be necessary to scrub with a bristle brush, and a second application may be needed. Mildew may not be completely removed from porous surfaces.
- Do not mix this product with any other chemicals.

CAUTION

Eye and skin irritant. In case of contact with eyes or skin, flush with water for 15 minutes. If irritation persists, seek medical attention. If swallowed, take large amounts of water. Do not induce vomiting. Get medical attention. Material Safety Data Sheet available.

DO NOT MIX THIS PRODUCT WITH ANY OTHER CHEMICALS.

KEEP OUT OF REACH OF CHILDREN.